



- www.C2Motorsports.net •
- sales@C2Motorsports.net • tech@C2Motorsports.net •

502.895.3660

Thank you for purchasing another great product from C2Motorsports. Please follow the list below of simple instructions before installing your new SS Head Spacer:

1. Make sure a qualified automotive technician undertakes the installation.
2. Clean the SS spacer with a mild solvent prior to installation, just to make sure there is no foreign debris present that might inhibit the bond between the layers.
3. Remove rivets ****shipping purposes only****
4. The use of a “gasket prep” spray (Permatex 80697) is required when installing. **DO NOT** use head adhesive.
5. All items have undergone a quality control inspection prior to leaving our facility....but please double check everything before installation.
6. Torque all bolts to VW factory specifications.
7. This is a “race” only item that is to be used on off-road vehicles only.
8. The operator/installer of this item accepts all responsibility for the proper installation and use of this product.
9. There are no expressed or implied warranties with this product.

If there is anything we may provide to you in the future, please do not hesitate to contact us.